



## Zubri Patio Heater

### Safety Guide

- Your Zubri heater is designed for use with a 20 lb. LP cylinder. No other size is recommended.
- Storage of your Zubri heater indoors is only permissible if the gas cylinder is disconnected and removed from the
- appliance. Store gas cylinders outdoors, in well-ventilated areas and out of reach of children.
- Heater is for outdoor use only!
- Carefully supervise children and animals in the area.
- Do not allow anyone to assemble or use if ill, tired, or under the influence of alcohol or drugs.
- Position on a level and stable surface capable of bearing its weight.
- Never carry or pull by its gas supply hose.
- Always turn heat control knob and gas bottle valve off when not in use.
- Never use, or leave standing in wind, rain.
- Never leave it turned on while unattended.
- Watch your footing. Make sure the floor area around the heater is kept clear of trip-hazards and clean of any
- spillage.

**Warning!** Whenever you fit a new cylinder or if you suspect there are any gas leaks turn off the gas supply from the gas cylinder immediately. Mix up a dilute mixture of washing liquid and water. Turn the gas supply on again, with a small brush apply soapy liquid to suspected area, and observe. If a leak is present, bubbles will form. Never test with naked flame. Under no circumstances, use this equipment if you suspect a gas leak.

**Warning!** Whenever the gas is not in use, you must turn off the gas supply from the gas cylinder.

**Warning!** The emitter and reflector reach high surface temperatures. To avoid injury, do not touch for minutes after being switched off.

#2 – 1660 Powick Rd. Kelowna, BC V1X 7G5  
T: 250 861-1575 F: 250 861-9052 TF: 1 800 640-3190  
[www.avalonrents.com](http://www.avalonrents.com)

Your Vision Is Our Mission!

## **Assembly**

1. Attach legs to control cone. Depress clutch spring on leg and slide leg into leg holder on control cone. Make sure clutch spring locks into hole in leg holder.
2. Attach deflector. Place center hole of reflector over folding wing nut and slide reflector onto emitter.
3. Unfold the folding wing nut and screw down onto the reflector until reflector is held firmly onto emitter. Over tightening the folding wing nut can damage the reflector.
4. Wrap skirt around legs. Secure with velcro at top. Zip up. Move skirt so that zip runs down one of the legs.

## **Connecting the Propane Cylinder**

1. Lift gas/propane cylinder onto hook so cylinder is suspended.

Warning: Cylinders are heavy & may cause injury. Important! Cylinder adds important weight to the Zubri heater and helps to keep it stable.

## **Lighting the heater**

1. Turn on gas supply from gas/propane cylinder.
  2. Hold flame under burner head.
  3. Start gas flow. Push in control knob and turn counterclockwise. Gas will ignite.
- Important: Keep control knob pushed in for at least 15 seconds. This will allow the safety couple device to heat up. If the thermocouple is not heated correctly the gas supply will automatically cut off. If flame goes out for anyreason wait 2 minutes and repeat step 2 and 3.

## **Adjusting heat**

1. Push in control knob and turn counterclockwise to increase heat or clockwise to reduce heat.

## **Turn heater off and make safe**

1. Push in control knob and turning clockwise until stop. Flame will go out. Turn off gas supply on propane cylinder.

### **Cleaning**

1. Do not attempt to clean heater while it is warm. General cleaning can be done with a damp soapy cloth followed by polishing with a soft cloth. Abrasive cleaners should never be used.
2. Turn off gas at cylinder valve.
3. Remove reflector by unscrewing securing nut. Clean reflector with damp soapy cloth followed by polishing with soft cloth. Important! Treat the reflector with care as it can bend or dent if you handle it roughly.